

```
[GLOBAL]
LOGIC_CORE_PATH = /usr/lib/arm-linux-gnueabi/hf/svxlink
LOGICS = SimplexLogic,ReflectorLogic
CFG_DIR = svxlink.d
TIMESTAMP_FORMAT = "%d.%m.%Y %H:%M:%S"
CARD_SAMPLE_RATE = 48000
CARD_CHANNELS = 1
#LOCATION_INFO = LocationInfo
LINKS = LinkToReflector
```

```
[SimplexLogic]
TYPE = Simplex
RX = Rx1
TX = MultiTx
MODULES = ModuleHelp,ModuleParrot,ModuleEchoLink
CALLSIGN = OE5LAL-HS
SHORT_IDENT_INTERVAL = 15
LONG_IDENT_INTERVAL = 30
EVENT_HANDLER = /usr/share/svxlink/events.tcl
DEFAULT_LANG = de_DE
RGR_SOUND_DELAY = 100
RGR_SOUND_ALWAYS = 1
MACROS = Macros
FX_GAIN_NORMAL = 0
FX_GAIN_LOW = -25
DTMF_CTRL_PTY = /tmp/dtmf_svx
```

```
[ReflectorLogic]
TYPE = ReflectorV2
HOSTS = oe9xvi.dyndns.org:5300
CALLSIGN = OE1XXX-HS
AUTH_KEY = xxxxxxxxxxxxxx
DEFAULT_TG = 2325
MONITOR_TGS = 23211,23251, 232,
TG_SELECT_TIMEOUT = 30
ANNOUNCE_REMOTE_MIN_INTERVAL = 300
EVENT_HANDLER = /usr/share/svxlink/events.tcl
NODE_INFO_FILE = /etc/svxlink/node_info.json
QSY_PENDING_TIMEOUT = 15
TMP_MONITOR_TIMEOUT = 3600
UDP_HEARTBEAT_INTERVAL = 15
DEFAULT_LANG = de_DE
VERBOSE = 0
```

```
[LinkToReflector]
CONNECT_LOGICS = SimplexLogic:9:,ReflectorLogic
DEFAULT_ACTIVE = 1
OPTIONS = DEFAULT_CONNECT,NO_DISCONNECT
TIMEOUT = 300
```

```
[Macros]
1 = EchoLink:9999#
9 = Parrot:0123456789#
```

03400 = EchoLink:9999#

[Rx1]

TYPE = Local

AUDIO\_DEV = alsa:plughw:CARD=Device,DEV=0

AUDIO\_CHANNEL = 0

SQL\_DET = HIDRAW

HID\_DEVICE = /dev/cm108gpio

HID\_SQL\_PIN = VOL\_DN

SQL\_START\_DELAY = 20

SQL\_DELAY = 200

SQL\_HANGTIME = 0

SQL\_TIMEOUT = 180

DEEMPHASIS = 1

SQL\_TAIL\_ELIM = 250

PREAMP = 0

#PEAK\_METER = 1

DTMF\_DEC\_TYPE = INTERNAL

DTMF\_MUTING = 1

DTMF\_HANGTIME = 40

DTMF\_SERIAL = /dev/ttyS0

#1750\_MUTING = 1

[MultiTx]

TYPE = Multi

TRANSMITTERS = Tx1,TxStream

[TxStream]

TYPE = Local

AUDIO\_DEV = alsa:plughw:CARD=Loopback,DEV=0

AUDIO\_CHANNEL = 0

PTT\_TYPE = NONE

TIMEOUT = 7200

TX\_DELAY = 0

PREEMPHASIS = 0

[Tx1]

TYPE = Local

TX\_ID = T

AUDIO\_DEV = alsa:plughw:CARD=Device,DEV=0

AUDIO\_CHANNEL = 0

LIMITER\_THRESH = -6

PTT\_TYPE = Hidraw

PTT\_PORT = /dev/ttyS0

PTT\_PIN = DTRRTS

HID\_DEVICE = /dev/cm108gpio

HID\_PTT\_PIN = GPIO3

TX\_DELAY = 600

PREEMPHASIS = 1

DTMF\_TONE\_LENGTH = 100

DTMF\_TONE\_SPACING = 50

DTMF\_DIGIT\_PWR = -15

[LocationInfo]

APRS\_SERVER\_LIST = euro.aprs2.net:14580

#STATUS\_SERVER\_LIST = aprs.echolink.org:5199

LON\_POSITION = 13.78.84E

LAT\_POSITION = 47.80.80N

CALLSIGN = EL-OE5LAL-HS

FREQUENCY = 433.XXX

#TX\_POWER = 1

ANTENNA\_GAIN = 6

ANTENNA\_HEIGHT = 1m

#ANTENNA\_DIR = -1

PATH = WIDE1-1

BEACON\_INTERVAL = 1000

#TONE = 136

COMMENT = SvxLinkby SM0SVX ([www.svxlink.org](http://www.svxlink.org))