

SVXLink Configurator für SVXLink IMAGE

NORMAL MODE

Global

Module_PATH	✓	/usr/lib/arm-linux-gnueabi/hf/svxlink	
LOGICS	✓	SimplexLogic,ReflectorLogic	
CFG_DIR	✓	svxlink.d	
TIMESTAMP_FORMAT	✓	"%d.%m.%Y %H:%M:%S"	
CARD_SAMPLE_RATE	✓	48000	
CARD_CHANNELS	✓	1	
LOCATION_INFO		LocationInfo	
LINKS	✓	LinkToReflector	

SimplexLogic

TYPE	✓	Simplex	
RX	✓	RX1	
TX	✓	MultiTX	
MODULES	✓	ModuleHelp,ModuleParrot,ModuleEchoLink	
CALLSIGN	✓	OE1xxx-HS	
SHORT_IDENT_INTERVAL	✓	15	
LONG_IDENT_INTERVAL	✓	30	
EVENT_HANDLER	✓	/usr/share/svxlink/events.tcl	
DEFAULT_LANG	✓	De DE	
RGR_SOUND_DELAY	✓	100	
RGR_SOUND_ALWAYS	✓	1	
MACROS	✓	Macros	
FX_GAIN_NORMAL	✓	0	
FX_GAIN_LOW	✓	-25	
DTMF_CTRL_PTY	✓	/tmp/dtmf_svx	

ReflectorLogic

Type	✓	ReflectorV2	
HOSTS	✓	oe9xvi.dyndns.org:5300	
CALLSIGN	✓	OE1xxx-HS	
AUTH_KEY	✓	xxxxxxxxxx	
DEFAULT_TG	✓	20	
MONITOR_TGS	✓	23211,232,	
TG_SELECT_TIMEOUT	✓	30	
ANNOUNCE_REMOTE_MIN_INTERVAL		300	
EVENT_HANDLER	✓	/usr/share/svxlink/events.tcl	
NODE_INFO_FILE	✓	/etc/svlink/node_info.json	
QSY_PENDING_TIMEOUT	✓	15	
TMP_MONITOR_TIMEOUT	✓	3600	
UDP_HEARTBEAT_INTERVAL	✓	15	
DEFAULT_LANG	✓	de_DE	
VERBOSE	✓	0	

LinkToReflector

CONNECT_LOGICS	√	SimplexLogic:9:,ReflectorLogic	
DEFAULT_ACTIVE	√	1	
OPTIONS	√	DEFAULT_CONNECT,NO_DISCONNECT	
TIMEOUT	√	300	

Macros

1	√	EchoLink:9999#	
9	√	Parrot:0123456789#	
03400	√	EchoLink:9999#	

RX1

TYPE	√	Local	
AUDIO_DEV	√	alsa:plughw:CARD=Device,DEV=0	
AUDIO_CHANNEL	√	0	
SQL_DET	√	HIDRAW	
HID_DEVICE	√	/dev/cm108gpio	
HID_SQL_PIN	√	VOL_DN	
SQL_START_DELAY	√	20	
SQL_DELAY	√	200	
SQL_HANGTIME	√	0	
SQL_TIMEOUT	√	180	
DEEMPHASIS	√	1	
SQL_TAIL_ELIM	√	250	
PREAMP	√	0	
PEAK_METER		1	
DTMF_DEC_TYPE	√	INTERNAL	
DTMF_MUTING	√	1	
DTMF_HANGTIME	√	40	
DTMF_SERIAL	√	/dev/ttyS0	
1750_MUTING		1	

MultiTx

TYPE	√	Multi	
TRANSMITTERS	√	Tx1,TxStream	

TxStream

TYPE	√	Local	
AUDIO_DEV	√	alsa:plughw:CARD=Loopback,DEV=0	
AUDIO_CHANNEL	√	0	
PTT_TYPE	√	NONE	
TIMEOUT	√	7200	
TX_DELAY	√	0	
PREEMPHASIS	√	0	

Tx1

TYPE	√	Local	
TX_ID	√	T	
AUDIO_DEV	√	alsa:plughw:CARD=Device,DEV=0	
AUDIO_CHANNEL	√	0	
LIMITER_THRESH	√	-6	
PTT_TYPE	√	Hidraw	
PTT_PORT	√	/dev/ttyS0	
PTT_PIN	√	DTRRTS	
HID_DEVICE	√	/dev/cm108gpio	
HID_PTT_PIN	√	GPIO3	
TX_DELAY	√	600	
PREEMPHASIS	√	1	
DTMF_TONE_LENGTH	√	100	
DTMF_TONE_SPACING	√	50	
DTMF_DIGIT_PWR	√	-15	

LocationInfo

APRS_SERVER_LIST	√	euro.aprs2.net:14580	
STATUS_SERVER_LIST	√	aprs.echolink.org:5199	
LON_POSITION	√	13.47.18E	
LAT_POSITION	√	47.48.16N	
CALLSIGN	√	EL-OE1xxx-HS	
FREQUENCY	√	433.150	
TX_POWER		1	
ANTENNA_GAIN	√	6	
ANTENNA_HEIGHT	√	1m	
ANTENNA_DIR		-1	
PATH	√	WIDE1-1	
BEACON_INTERVAL	√	1000	
TONE		136	